


ASSEMBLY INSTRUCTIONS HOODED GAS GRILL

Model: KYQ-301S; KYQ-401S; KYQ-401SR; KYQ-501S; KYQ-501SR; KYQ-601S



FOR OUTDOOR USE ONLY

PLEASE READ INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY

RETAIN THIS MANUAL FOR FUTURE REFERENCE

WARNING

Hazardous fire or explosion may result if instructions are ignored

It is the consumer's responsibility to see that the barbecue is properly assembled, installed, and taken care of. Failure to follow instructions in this manual could result in bodily injury and/or property damage.

FOR YOUR SAFETY IF YOU SMELL GAS:

1. Turn off gas supply at bottle.
2. Extinguish all naked flames; do not operate any electrical appliances.
3. Ventilate the area.
4. Check for leaks as detailed in this manual.
5. If odour persists, contact your dealer or gas supplier immediately.

PRECAUTIONS:

1. Leak test all connections after each tank refill.
2. Never check for leaks with a match or open flame.
3. Do not store or use gasoline or other flammable vapours and liquids in the vicinity of this or any other appliance.
4. Any LP cylinder not connected for use shall not be stored in the vicinity of this or any other appliance.

Assembly

WARNING: Whilst every effort has been made in manufacture of your barbecue to remove any sharp edge, you should handle all components with care to avoid accidental injury.


Tools required: Either a Philips crosshead or flat-bladed screwdriver and either a spanner (we have supplied a multifunction spanner) or a pair of pliers.

ASSEMBLY:

Please read all instructions thoroughly before proceeding. Find a large, clean area in which to assemble your trolley barbecue. Please refer to the parts list and assembly diagram as necessary. Assembly of the barbecue involves many large components, it is advisable to have two people assemble the unit.












NOTICE: Make sure all the plastic protection is ripped off before assembly













Expanded view KYQ-401S;KYQ-401SR;KYQ-501S;KYQ-501SR,KYQ-601S




KYQ-401S;KYQ-401SR;KYQ-501S;KYQ-501SR,KYQ-601S

PARTS LIST


NO.	DESCRIPTION	QTY
1		1
2		2 / 3
3		4 / 5
4		1
5		1
6		1
6		1
7		1
8		1
9		2
10		1

NO.	DESCRIPTION	QTY
11		1
12		1 / 2
13		2
14		1
15		1
16		2
17		1
18		0 / 1
19		1 / 2
20		2
21		1
22		1


Assembly KYQ-401S;KYQ-401SR;KYQ-501S;KYQ-501SR;KYQ-601S




M6X12X2 PCS
M6X16 PCS
M6X35X16 PCS



M6X12X9 PCS






M6X12X16 PCS
M6X8 PCS
KYQ-501S,
KYQ-501SR,
KYQ-601S




M6X12X8 PCS
M6X4 PCS



KYQ-401S,
KYQ-401SR





M6X12X4 PCS


1	2
3	3
4	5





 M6X12X4 PCS
 M6X2 PCS







 M6X12X2 PCS



 M6X12X8 PCS



 M6X12X9 PCS
 M6X1 PCS



6	6
7	8
9	10