

Broil King®

REDDI-BILT BARBECUES




Broil King®

MONARCH 320

9312-52

9312-53

9312-56




Broil King®

MONARCH 340

9312-62

9312-63

9312-66



Broil King®

MONARCH 390








9312-82

9312-83


9312-86





1




2




3




4





5

(4)  (2) 





6

(2) 





7

(6)





8

(2)






9

(1)








10









12

(1)



13



(1)


















14


9312-62 9312-82
9312-63 9312-83
9312-66 9312-86

(1)




15






17

9312-52 9312-63
9312-53 9312-82
9312-62 9312-83



18

9312-56
9312-66
9312-86




19


9312-82

9312-83

9312-86



20






21

9312-82

9312-83

9312-86



PARTS LIST / LISTE DES PIÉCES

ITEM #	ITEM #	DESCRIPTION	9312-52	9312-53	9312-56	9312-62	9312-63	9312-66	9312-82	9312-83	9312-86
1	10909-E340	CASTING BOTTOM	1	1	1	1	1	1	1	1	1
2	10473-E341	CASTING TOP	1	1	1	1	1	1	1	1	1
3	10081-BK630	NAMEPLATE	1	1	1	1	1	1	1	1	1
4	10958-E340	TOP CASTING INSERT	1	1	1	1	1	1	1	1	1
5	10571-6	HEAT INDICATOR	1	1	1	1	1	1	1	1	1
6	10240-15	HINGE PIN	2	2	2	2	2	2	2	2	2
6A	S21237	HINGE SPACER	2	2	2	2	2	2	2	2	2
7	S21233	HITCH PIN CLIP	5	5	5	5	5	5	5	5	5
8	Y-11542	SCREW - BURNER	3	3	3	3	3	3	3	3	3
9	10225-T356	GRID - PORCELAIN	2	2	2	2	2	2	2	2	2
10	10222-E400	FLAV-R-WAVE	1	1	1	1	1	1	1	1	1
11	10225-E341	GRID - WARMING RACK	1	1	1	1	1	1	1	1	1
12	10222-E301	DIVIDER	2	2	2	2	2	2	2	2	2
13	10184-R83	BOSS EXTENSION	1	1	1	1	1	1	1	1	1
15	10390-E20D	BURNER	3	•	•	3	•	•	3	•	•
	10390-E20E	BURNER	•	3	3	•	3	3	•	3	3
17	10342-245	ELECTRONIC IGNITOR	1	1	1	•	•	•	•	•	•
	10342-246	ELECTRONIC IGNITOR	•	•	•	1	1	1	•	•	•
	10342-247	ELECTRONIC IGNITOR	•	•	•	•	•	•	1	1	1
18	10342-E12	ELECTRODE	2	2	2	2	2	2	2	2	2
19	52224-224A	COLLECTOR BOX	1	1	1	1	1	1	1	1	1
20	10111-16A	HOSE ASSEMBLY	1	1	1	1	1	1	1	1	1
21	29004-012	CONTROL ASSEMBLY	1	•	•	•	•	•	•	•	•
	29004-013	CONTROL ASSEMBLY	•	1	•	•	•	•	•	•	•
	29004-016	CONTROL ASSEMBLY	•	•	1	•	•	•	•	•	•
	29004-032	CONTROL ASSEMBLY	•	•	•	1	•	•	•	•	•
	29004-033	CONTROL ASSEMBLY	•	•	•	•	1	•	•	•	•
	29004-039	CONTROL ASSEMBLY	•	•	•	•	•	1	•	•	•
	29004-072	CONTROL ASSEMBLY	•	•	•	•	•	•	1	•	•
	29004-073	CONTROL ASSEMBLY	•	•	•	•	•	•	•	1	•
	29004-076	CONTROL ASSEMBLY	•	•	•	•	•	•	•	•	1
21A	S13470-073	HOSE-SIDE BURNER	•	•	•	1	•	•	1	•	•
	S13470-079	HOSE-SIDE BURNER	•	•	•	•	1	•	•	1	•
	S13470-109	HOSE-SIDE BURNER	•	•	•	•	•	1	•	•	1
21B	Y-11230	COTTER PIN	•	•	•	1	1	1	1	1	1
21C	10110-34	TUBE-REAR BURNER ASSY	•	•	•	•	•	•	1	1	1
23	10472-K431	CONTROL KNOB	3	3	3	4	4	4	5	5	5
30	10194-F137	CONTROL COVER	1	1	1	•	•	•	•	•	•
	10194-F157	CONTROL COVER	•	•	•	1	1	1	•	•	•
	10194-F197	CONTROL COVER	•	•	•	•	•	•	1	1	1
31	10711-E34	EDGE CAP - CONTROL COVER	1	1	1	1	1	1	1	1	1
32	10711-E33	EDGE CAP - CONTROL COVER	1	1	1	1	1	1	1	1	1
33	10184-E96	RADIATION SHIELD	1	1	1	1	1	1	1	1	1
34	10184-E97	GREASE RAIL	1	1	1	1	1	1	1	1	1
35	10184-E501	SUPPORT-CASTING-LEFT	1	1	1	1	1	1	1	1	1
36	10184-E511	SUPPORT-CASTING-RIGHT	1	1	1	1	1	1	1	1	1
37	10184-E651	SUPPORT-SIDE SHELF-LEFT	2	2	2	2	2	2	2	2	2
37A	10184-E63	SUPPORT-SIDE SHELF-LEFT	2	2	2	2	2	2	2	2	2
38	10184-E641	SUPPORT-SIDE SHELF-RIGHT	2	2	2	2	2	2	2	2	2
38A	10184-E62	SUPPORT-SIDE SHELF-RIGHT	2	2	2	2	2	2	2	2	2
39	10956-E421	BRACE-REAR	1	1	1	1	1	1	1	1	1
40	10958-E71	BASE	1	1	1	1	1	1	1	1	1
41	10956-E311	BRACE-FRONT	1	1	1	1	1	1	1	1	1
43	10958-E761	SIDE PANEL	2	2	2	2	2	2	2	2	2
44	10958-E361	REAR PANEL	1	1	1	1	1	1	1	1	1
45	10184-E981	BRACKET - DOOR CATCH	1	1	1	1	1	1	1	1	1
48	10184-E691	SHELF BRACKET	2	2	2	2	2	2	2	2	2
50	10711-E822	SHELF - SIDE - RIGHT	1	1	1	1	1	1	1	1	1
51	10711-E822	SHELF - SIDE - RIGHT	1	1	1	•	•	•	•	•	•
	10711-E832	SHELF-SIDEBURNER	•	•	•	1	1	1	1	1	1
56	10892-7G	WHEEL	2	2	2	2	2	2	2	2	2
60	10711-E49	END CAP - SHELF - RIGHT	2	2	2	2	2	2	2	2	2

PARTS LIST / LISTE DES PIÉCES

KEY #	ITEM #	DESCRIPTION	9312-52	9312-53	9312-56	9312-62	9312-63	9312-66	9312-82	9312-83	9312-86
66	S13006AE	BURNER ROTISSERIE	•	•	•	•	•	•	1	1	1
68	S21362	SPRING	•	•	•	•	•	•	1	1	1
69	10958-E48A	DOOR	1	1	1	1	1	1	1	1	1
70	21475-138A	HANDLE	1	1	1	1	1	1	1	1	1
71	10696-085	REARBURNER-ORIFICE	•	•	•	•	•	•	1	•	•
	10696-094	REARBURNER-ORIFICE	•	•	•	•	•	•	•	1	•
	10696-145	REARBURNER-ORIFICE	•	•	•	•	•	•	•	•	1
72	S21420	PUSH NUT	2	2	2	2	2	2	2	2	2
73	Y-11990	HEX NUT	•	•	•	•	•	•	1	1	1
74	S21084	SCREW - #14 x 3/4	2	2	2	2	2	2	2	2	2
75	10184-E302A	HANDLE	1	1	1	1	1	1	1	1	1
78	10892-13	CASTOR	2	2	2	2	2	2	2	2	2
79	Y-11561	BOLT – 1/4:20 x 1 3/4	12	12	12	12	12	12	12	12	12
80	Y-11546	SCREW - 1/4-20 X 5/8	8	8	8	8	8	8	8	8	8
81	Y-12860	SCREW – 1/4-20 X 1 3/8	4	4	4	4	4	4	4	4	4
82	Y-12673	SHELF - LOCK PIN	2	2	2	2	2	2	2	2	2
83	Y-12865	BOLT- 1/4-20 X 1/2	8	8	8	8	8	8	8	8	8
84	S15170	AXLE	1	1	1	1	1	1	1	1	1
85	Y-12855	BOLT- 1/4-20 X 3/8	8	8	8	8	8	8	8	8	8
87	Y-11793	NUT- 1/4-20	18	18	18	18	18	18	18	18	18
96	S21125	SCREW – 8 X 1/2	4	4	4	4	4	4	4	4	4
98	S21124	SCREW – 8 X 1/2	33	33	33	34	34	34	35	35	35
99	Y-12646	SCREW – SHOULDER 8 X 1/2	•	•	•	2	2	2	2	2	2
104	Y-12835	SCREW – 6-32 X 1/4	•	•	•	2	2	2	2	2	2
105	Y-12953	WASHER	•	•	•	2	2	2	2	2	2
106	Y-12861	SCREW – 1/4-20 X 3/8	•	•	•	2	2	2	2	2	2
107	Y-12863	WASHER	•	•	•	4	4	4	4	4	4
110	53140-981	GRID	•	•	•	1	1	1	1	1	1
111	10390-E10D	SIDE BURNER	•	•	•	1	•	•	1	•	•
	10390-E10E	SIDE BURNER	•	•	•	•	1	1	•	1	1
113	10342-T16	ELECTRODE – SIDE BURNER	•	•	•	1	1	1	1	1	1
114	23000-255	COVER-SIDE BURNER	•	•	•	1	1	1	1	1	1
115	Y-29304	SCREW #10-24 X 3/8	2	2	2	2	2	2	2	2	2
117	23000-271	SHELF-SIDE BURNER	•	•	•	1	1	1	1	1	1
122	57054-902	GREASE TRAY	1	1	1	1	1	1	1	1	1
123	52009-902	GREASE PAN	1	1	1	1	1	1	1	1	1
135	Y-12119	BUSHING	2	2	2	3	3	3	3	3	3
136	10184-E44	ROTISSERIE SHIELD	1	1	1	1	1	1	1	1	1
137	10184-E42	ROTISSERIE BRACKET	1	1	1	1	1	1	1	1	1
138	10184-E43	ROTISSERIE SHIELD	1	1	1	1	1	1	1	1	1
139	S21061	WING NUT	2	2	2	2	2	2	2	2	2
140	Y-29306	BOLT - 10-24 x 5/8	2	2	2	2	2	2	2	2	2
141	S15271	HANDLE	•	•	•	•	•	•	1	1	1
142	S15270	BALANCER	•	•	•	•	•	•	1	1	1
143	S15263	BUSHING	•	•	•	•	•	•	1	1	1
144	Y-12220	BUSHING	•	•	•	•	•	•	1	1	1
145	S15256	SPIT ROD	•	•	•	•	•	•	1	1	1
146	S15242	MOTOR	•	•	•	•	•	•	1	1	1
147	S15299	WASHER	•	•	•	•	•	•	1	1	1
148	S15287	4 PRONG FORKS	•	•	•	•	•	•	1	1	1
149	10240-20	DOOR PIN	1	1	1	1	1	1	1	1	1
152	Y-12222	MAGNET	1	1	1	1	1	1	1	1	1
153	Y-12223	SNAP IN MAGNET	1	1	1	1	1	1	1	1	1
164	Y-12124	DOOR CAP	1	1	1	1	1	1	1	1	1
165	Y-11551	SCREW 1/4-20 X 1	1	1	1	1	1	1	1	1	1

