

# Broil King®

---

---



## Broil King.

SIGNET 320  
9868-52  
9868-53  
9868-56



## Broil King.












SIGNET 340  
9868-62  
9868-63  
9868-66






## Broil King.

SIGNET 390  
9868-82  
9868-83  
9868-86

## HARDWARE INCLUDED







S21420		X2	Y-11561		X 4
Y-11793		X2	Y-12865		X8
AAA		X1	Y-29340		X2
S21124		X2	Y-12124		X2
Y-12673		X2	Y-29306		X2
S21061		X2			

## TOOLS REQUIRED




1


(2)



2





3





4

(4)



5

(2)





6


(1)




(2)




7


(2) 






8



(6) 




9

(2) 






(2)








# 11

(1)






# 12

(1)










# 13

(1)





# 14






16




17










# 18



# 19



# 20



**PARTS LIST / LISTE DES PIECES**

KEY #	ITEM #	DESCRIPTION	9868-52	9868-53	9868-62	9868-63	9868-82	9868-83	9868-86
1	10909-E401	CASTING BOTTOM	1	1	1	1	1	1	1
2	10473-E400	CASTING TOP	1	1	1	1	1	1	1
3	10081-BK630	NAMEPLATE	1	1	1	1	1	1	1
4	10958-E400A	TOP CASTING INSERT	1	1	1	1	1	1	1
5	10571-6	HEAT INDICATOR	1	1	1	1	1	1	1
6	10240-15	HINGE PIN	2	2	2	2	2	2	2
6A	S21237	HINGE SPACER	2	2	2	2	2	2	2
7	S21233	HITCH PIN CLIP	2	2	2	2	2	2	2
9	10225-T436	GRID	2	2	2	2	2	2	2
10	10222-E400	FLAV-R-WAVE	3	3	3	3	3	3	3
11	10225-E401	GRID - WARMING RACK	1	1	1	1	1	1	1
12	10222-E401	DIVIDER	2	2	2	2	2	2	2
13	10184-R83	BOSS EXTENSION	1	1	1	1	1	1	1
15	10390-E20D	BURNER	3	•	3	•	3	•	•
	10390-E20E	BURNER	•	3	•	3	•	3	•
	10390-E20NGE	BURNER	•	•	•	•	•	•	3
17	10342-245	ELECTRONIC IGNITOR	1	1	•	•	•	•	•
	10342-246	ELECTRONIC IGNITOR	•	•	1	1	•	•	•
	10342-247	ELECTRONIC IGNITOR	•	•	•	•	1	1	1
18	10342-E12	ELECTRODE	2	2	2	2	2	2	2
19	10342-E400A	COLLECTOR BOX	1	1	1	1	1	1	1
20	10111-16A	PIGTAIL HOSE ASSEMBLY	1	1	1	1	1	1	1
21	10444-E40D	CONTROL ASSEMBLY -2	1	•	•	•	•	•	•
	10444-E30E	CONTROL ASSEMBLY -3	•	1	•	•	•	•	•
	10444-E42D	CONTROL ASSEMBLY -2	•	•	1	•	•	•	•
	10444-E32E	CONTROL ASSEMBLY -3	•	•	•	1	•	•	•
	10444-E36D	CONTROL ASSEMBLY -2	•	•	•	•	1	•	•
	10444-E36E	CONTROL ASSEMBLY -3	•	•	•	•	•	1	•
	10444-E37E	CONTROL ASSEMBLY -6	•	•	•	•	•	•	1
21A	S13470-073	SIDE BURNER HOSE	•	•	1	•	1	•	•
	S13470-079	SIDE BURNER HOSE	•	•	•	1	•	1	•
	S13470-109	SIDE BURNER HOSE	•	•	•	•	•	•	1
21B	Y-11230	HOSE CLIP	•	•	1	1	1	1	1
21C	10110-40	TUBE - REAR BURNER ASSY	•	•	•	•	1	1	1

**PARTS LIST / LISTE DES PIECES**

KEY #	ITEM #	DESCRIPTION	9868-52	9868-53	9868-62	9868-63	9868-82	9868-83	9868-86
23	22001-768	CONTROL KNOB	3	3	4	4	5	5	5
23A	10472-E38	CONTROL BEZEL	3	3	4	4	5	5	5
30	10194-E433	CONTROL COVER	1	1	•	•	•	•	•
	10194-E455	CONTROL COVER	•	•	1	1	•	•	•
	10194-E499	CONTROL COVER	•	•	•	•	1	1	1
31	10711-E42A	EDGE CAP - CONTROL COVER	1	1	1	1	1	1	1
32	10711-E41A	EDGE CAP - CONTROL COVER	1	1	1	1	1	1	1
33	10184-F96	RADIATION SHIELD	1	1	1	1	1	1	1
34	10184-F97	GREASE RAIL	1	1	1	1	1	1	1
35	10184-E501	SUPPORT-CASTING-LEFT	1	1	1	1	1	1	1
36	10184-E511	SUPPORT-CASTING-RIGHT	1	1	1	1	1	1	1
37	10184-E651	SUPPORT-SIDE SHELF-LEFT	2	2	2	2	2	2	2
37A	10184-E63	SUPPORT-SIDE SHELF-LEFT	2	2	2	2	2	2	2
38	10184-E641	SUPPORT-SIDE SHELF-RIGHT	2	2	2	2	2	2	2
38A	10184-E62	SUPPORT-SIDE SHELF-RIGHT	2	2	2	2	2	2	2
39	10956-E881	BRACE-REAR	1	1	1	1	1	1	1
40	10958-E81	BASE	1	1	1	1	1	1	1
41	10956-E591	BRACE-FRONT	1	1	1	1	1	1	1
42	10958-E79	DOOR	2	2	2	2	2	2	2
42A	10958-E851	DOOR - INNER	2	2	2	2	2	2	2
43	10958-E761	SIDE PANEL	2	2	2	2	2	2	2
44	10958-E901	PANEL - REAR	1	1	1	1	1	1	1
45	10184-E931	BRACKET - DOOR CATCH	1	1	1	1	1	1	1
48	10184-E681	SHELF BRACKET	2	2	2	2	2	2	2
49	10711-E84	CONDI-BIN - SHELF	2	2	2	2	2	2	2
50	10711-E92	SHELF	1	1	1	1	1	1	1
51	10711-E93	SHELF - SB	•	•	1	1	1	1	1
	10711-E92	SHELF	1	1	•	•	•	•	•
52	10184-E78A	DOOR - TOP CAP - LEFT	1	1	1	1	1	1	1
53	10184-E76	DOOR - BOTTOM CAP - LEFT	1	1	1	1	1	1	1
54	10184-E79A	DOOR - TOP CAP - RIGHT	1	1	1	1	1	1	1
55	10184-E77	DOOR - BOTTOM CAP - RIGHT	1	1	1	1	1	1	1
56	10892-7G	WHEEL	2	2	2	2	2	2	2
60	10711-E47	END CAP - SHELF - RIGHT	1	1	1	1	1	1	1

**PARTS LIST / LISTE DES PIECES**

KEY #	ITEM #	DESCRIPTION	9868-52	9868-53	9868-62	9868-63	9868-82	9868-83	9868-86
62	10711-E45	END CAP - SHELF - RIGHT FRONT	1	1	1	1	1	1	1
63	10711-E48	END CAP - SHELF - LEFT	1	1	1	1	1	1	1
65	10711-E46	END CAP - SHELF - LEFT FRONT	1	1	1	1	1	1	1
66	S13005AE	BURNER ROTISSERIE	•	•	•	•	1	1	1
67	S15508	ELECTRODE	•	•	•	•	1	1	1
68	S21362	SPRING	•	•	•	•	1	1	1
71	10696-095	REARBURNER-ORIFICE	•	•	•	•	1	•	•
	10696-102	REARBURNER-ORIFICE	•	•	•	•	•	1	•
	10696-157	REARBURNER-ORIFICE	•	•	•	•	•	•	1
72	S21420	PUSH NUT	2	2	2	2	2	2	2
73	Y-11990	HEX NUT	•	•	•	•	1	1	1
74	S21084	SCREW - #14 x 3/4	9	9	9	9	9	9	9
75	10184-E702A	HANDLE	1	1	1	1	1	1	1
76	S21255	WASHER	2	2	2	2	2	2	2
78	10892-15	CASTOR	2	2	2	2	2	2	2
79	Y-11561	BOLT – 1/4:20 x 1 3/4	8	8	8	8	8	8	8
80	Y-11546	SCREW- 1/4-20 X 5/8	8	8	8	8	8	8	8
81	Y-12860	SCREW – 1/4-20 X 1 3/8	8	8	8	8	8	8	8
82	Y-12673	SHELF - LOCK PIN	2	2	2	2	2	2	2
83	Y-12855	SCREW 1/4-20 X 3/8	4	4	4	4	4	4	4
84	S15170	AXLE	1	1	1	1	1	1	1
85	Y-12865	SCREW- 1/4-20 X 1/2	8	8	8	8	8	8	8
87	Y-11793	NUT- 1/4-20	10	10	10	10	10	10	10
96	S21125	SCREW – 8 X 1/2	16	16	16	16	16	16	16
98	S21124	SCREW – 8 X 1/2	25	25	26	26	27	27	27
98A	Y-12643	SCREW – 8 X 1/2	12	12	12	12	12	12	12
99	Y-12646	SCREW – 8 X 1/2	•	•	2	2	2	2	2
104	Y-12835	SCREW – 6-32 X 1/4	•	•	2	2	4	4	4
105	Y-12853	WASHER	•	•	2	2	2	2	2
106	Y-12861	CAP SCREW - 1/4-20 X 3/8	•	•	2	2	2	2	2
107	Y-12863	WASHER	•	•	4	4	4	4	4
110	53140-981	GRID	•	•	1	1	1	1	1

**PARTS LIST / LISTE DES PIECES**

KEY #	ITEM #	DESCRIPTION	9868-52	9868-53	9868-62	9868-63	9868-82	9868-83	9868-86
111	10390-E10D	SIDE BURNER	•	•	1	•	1	•	•
	10390-E10E	SIDE BURNER	•	•	•	1	•	1	•
	10390-E10EN	SIDE BURNER	•	•	•	•	•	•	1
113	10342-T16	ELECTRODE – SB	•	•	1	1	1	1	1
114	23000-254	COVER-SIDE BURNER	•	•	1	1	1	1	1
115	Y-29304	SCREW 10-24 X 3/8	2	2	2	2	2	2	2
117	23000-271	SHELF-SIDE BURNER	•	•	1	1	1	1	1
122	57054-901	GREASE TRAY	1	1	1	1	1	1	1
123	52009-901	GREASE PAN	1	1	1	1	1	1	1
124	52049-91	SHIELD - GREASE TRAY	1	1	1	1	1	1	1
135	Y-12119	3/8 HEYCO BUSHING	2	2	3	3	3	3	3
136	10184-E43	ROTISSERIE SHIELD	1	1	1	1	1	1	1
137	10184-E42	ROTISSERIE BRACKET	1	1	1	1	1	1	1
138	10184-E44	ROTISSERIE SHIELD	1	1	1	1	1	1	1
139	S21061	WING NUT	2	2	2	2	2	2	2
140	Y-29306	BOLT - 10-24 x 3/4	2	2	2	2	2	2	2
141	S15271	HANDLE	•	•	•	•	1	1	1
142	S15270	BALANCER	•	•	•	•	1	1	1
143	S15263	BUSHING	•	•	•	•	1	1	1
144	Y-12220	BUSHING	•	•	1	1	1	1	1
145	S15257	SPIT ROD	•	•	•	•	1	1	1
146	S15246	ROTISSERIE MOTOR	•	•	•	•	1	1	1
147	S15299	WASHER	•	•	•	•	1	1	1
148	S15287	4 PRONG FORKS	•	•	•	•	2	2	2
155	Y-12124	DOOR PIN CAP	2	2	2	2	2	2	2
166	Y-12117	BUSHING	•	•	2	2	2	2	2

